



OPTIONS
 Support feet and brine connection flanges are considered optionals on request

BRINE CONNECTION POSITION
 Brine connections are placed on top of the unit as per standard.
 On request they can be placed alternatively on right side or left side (seen from refrigerant connection side)

EQUIPMENT
 As per standard, units are delivered with following equipment included:

- Gruvlock and counter-attack brine (if flex-joint);
- Additional flange brine with screws (if flange)
- Refrigerant connections in a separate box (if flanged)



ATTENTION! Informations and dimensions in this document are as a rough guide

	NAME	DATE	IF NOT SPECIFIED: DIMENSIONS IN MILLIMETERS	N. DISEGNO	A3
DESIGNER	N. Domenighini	14-11-2012		DXS505_2P	
VERIFIED					
APPROVED			REVISION: 01	SCALE:1:15	SHEET 1 OF 1